| Δ | |
|---|--|
| А | |

| A/C | 210 |
|---------------------------------|-------|
| ABS | 187 |
| ACCESSORY mode | 130 |
| Air conditioning filter | 414 |
| Air conditioning system | |
| Air conditioning filter | 414 |
| Automatic air conditioning | |
| system | 210 |
| Airbags | |
| Airbag operating conditions | 94 |
| Airbag precautions for your | |
| child | 98 |
| Airbag warning light | .454 |
| Curtain shield airbag operating | |
| conditions | 94 |
| Curtain shield airbag | |
| precautions | 98 |
| Front passenger occupant | |
| classification system | 103 |
| General airbag precautions | 98 |
| Locations of airbags | 91 |
| Modification and disposal of | |
| airbags | 102 |
| Proper driving posture80 | 9, 98 |
| Side airbag operating | |
| conditions | 94 |
| Side airbag precautions | 98 |
| SRS airbags | 91 |

| .larm | 85 | |
|------------------------------------|-------|--|
| Intenna | .228 | |
| nti-lock brake system | 187 | |
| rmrest | .340 | |
| \shtrays | .335 | |
| rudio input | .265 | |
| rudio system | | |
| Antenna | . 228 | |
| Audio input | 265 | |
| AUX port | 265 | |
| Bluetooth® audio | 270 | |
| CD player/changer | 231 | |
| iPod | 246 | |
| MP3/WMA disc | 238 | |
| Optimal use | 263 | |
| Portable music player | 265 | |
| Radio | 223 | |
| Steering wheel audio switch | 267 | |
| USB memory | . 254 | |
| USB port246 | , 254 | |
| automatic air conditioning | | |
| system | 210 | |
| outomatic headlight leveling | | |
| system | 160 | |
| مسملون والمسلسم والماسال والمسملان | 150 | |

| Automatic transmission | | C | Care | |
|-------------------------------|-----|---|-----------------------------|---------|
| Automatic transmission | 134 | | Exterior | 366 |
| If the shift lever cannot be | | | Interior | 369 |
| shifted from P | 487 | | Seat belts | 370 |
| M mode | 139 | | Cargo capacity | 200 |
| AUX port | 265 | | Cargo hooks | |
| Auxiliary box | | | CD changer | |
| | | | CD player | 231 |
| Back-up lights | | | Chains | |
| Wattage | 512 | | Child restraint system | |
| Battery | | | Booster seats, definition | 108 |
| Checking | 393 | | Booster seats, installation | 114 |
| If the vehicle has a discharg | | | Convertible seats, definiti | on108 |
| battery | | | Convertible seats, installa | tion114 |
| Preparing and checking | | | Front passenger occupar | nt |
| before winter | 204 | | classification system | 103 |
| Bluetooth [®] audio | | | Infant seats, definition | 108 |
| Bluetooth [®] phone | | | Infant seats, installation | 114 |
| Bottle holders | | | Installing CRS with lower | |
| Brake | | | anchorages | 113 |
| Fluid | 391 | | Installing CRS with seat b | elts114 |
| Parking brake | | | Installing CRS with top st | raps118 |
| Brake assist | | | | |

В

| Child safety |
|-----------------------------------|
| Airbag precautions98 |
| Battery precautions395, 494 |
| Child restraint system108 |
| Child-protectors43 |
| How your child should wear |
| the seat belt63 |
| Installing child restraints112 |
| Moon roof precautions79 |
| Power window lock switch73 |
| Power window precautions75 |
| Removed electronic key battery |
| precautions418 |
| Seat belt comfort guide61 |
| Seat belt extender precautions 65 |
| Seat belt precautions64 |
| Seat heater precautions339 |
| Trunk precautions48 |
| Child-protectors43 |
| Cigarette lighter336 |
| Cleaning |
| Exterior366 |
| Interior369 |
| Seat belts370 |
| Clock331 |

| Coat hooks343 |
|---------------------------------|
| Compass354 |
| Condenser391 |
| Console box324 |
| Cooling system |
| Engine overheating495 |
| Cornering assist sensors181 |
| Cruise control |
| Cruise control166 |
| Dynamic radar cruise control169 |
| Cup holders326 |
| Curtain shield airbags91 |
| Customizable features528 |
| |
| Daytime running light system |
| Defogger |
| Rear window218 |
| Side mirrors218 |
| Dimension502 |
| Dinghy towing207 |
| Display |
| Dynamic radar cruise control169 |
| Satellite switch mode332 |
| Trip information154 |
| Warning message463 |

| | Do-it-yourself maintenance 378 | | |
|---|---------------------------------------|--|--|
| | Door courtesy lights | | |
| | Door courtesy lights319 | | |
| | Wattage512 | | |
| | Door pockets328 | | |
| | Doors | | |
| | Door lock28, 39, 42 | | |
| | Door windows73 | | |
| | Side mirrors71 | | |
| | Driver's seat belt reminder light 456 | | |
| | Driving | | |
| | Correct posture89 | | |
| | Procedures122 | | |
| | Driving position memory51 | | |
| | | | |
| Ε | Electric power steering187 | | |
| | Electronic key | | |
| | If the electronic key does not | | |
| | operate properly489 | | |
| | Emergency flashers | | |
| | Switch442 | | |
| | | | |

| If the engine will not start486 |
|-----------------------------------|
| If the shift lever cannot be |
| |
| shifted from P487 |
| If the vehicle has a discharged |
| battery492 |
| If the warning buzzer sounds453 |
| If the warning light turns on453 |
| If a warning message is |
| displayed463 |
| If you have a flat tire477 |
| lf you lose your keys488 |
| If you think something is |
| wrong44 ^Q |
| If the electronic key does not |
| operate properly489 |
| lf your vehicle becomes stuck 498 |
| If your vehicle has to be |
| stopped in an emergency 499 |
| If your vehicle needs to be |
| towed443 |
| If your vehicle overheats495 |

| Engine | |
|------------------------------|-----|
| ACCESSORY mode | 130 |
| Compartment | 384 |
| Engine switch | 130 |
| Hood | 381 |
| How to start the engine | 130 |
| Identification number | 503 |
| If the engine will not start | 486 |
| Ignition switch | 130 |
| Overheating | 495 |
| Engine compartment cover | 385 |
| Engine coolant | |
| Capacity | 507 |
| Checking | 389 |
| Preparing and checking | |
| before winter | 204 |
| Engine coolant temperature | |
| gauge | 146 |
| Engine immobilizer system | 83 |
| Engine oil | |
| Capacity | 506 |
| Checking | 386 |
| Preparing and checking | |
| before winter | 204 |
| Engine oil maintenance data | 388 |
| EPS | 187 |
| Event data recorder | 451 |

| First-aid kit storage belt345 | | | |
|-------------------------------|-----|--|--|
| Floor mat | 344 | | |
| Fluid | | | |
| Brake | 391 | | |
| Washer | 396 | | |
| Fog lights | | | |
| Switch | 161 | | |
| Wattage | 512 | | |
| Footwell lights | | | |
| Front fog lights | | | |
| Switch | 161 | | |
| Wattage | 512 | | |
| Front passenger occupant | | | |
| classification system | 103 | | |
| Front passenger's seat belt | | | |
| reminder light | 456 | | |
| Front seats | | | |
| Adjustment | 50 | | |
| Driving position memory | | | |
| Seat position memory | | | |
| Front turn signal lights | | | |
| Switch | 143 | | |
| Wattage | | | |

| | Fuel | Headlight cleaner | 165 |
|---|------------------------------|---------------------------|------|
| | Capacity505 | Headlights | |
| | Fuel gauge146 | Discharge headlight | |
| | Fuel pump shut off system450 | precautions | 439 |
| | Gas station information568 | Replacing light bulbs | 435 |
| | Information513 | Switch | 158 |
| | Refueling80 | Wattage | 512 |
| | Fuel door80 | Heaters | |
| | Fuel filler door80 | Seat heaters | .338 |
| | Fuel pump shut off system450 | Side mirrors | 218 |
| | Fuses419 | Hill-start assist control | 187 |
| | | Hood | 381 |
| G | Garage door opener | Hooks | |
| | Gas station information568 | Cargo | 345 |
| | Gauges146 | Coat | 343 |
| | Glove box324 | Shopping bag | 345 |
| | Glove box light324 | Horn | 145 |
| | - | | |
| Н | Hands-free system for mobile | I/M test | .377 |
| | phone288 | Identification | |
| | Hazard lights | Engine | .503 |
| | Switch442 | Vehicle | .503 |
| | Head restraints | Ignition switch | 130 |
| | Adjusting57 | Illuminated entry system | 319 |
| | Headlight aim 433 | Indicator lights | 150 |
| | 3 | | |

| | Initialization | Lexus Enform* |
|---|--------------------------------|--------------------------------|
| | Items to initialize533 | Light bulbs |
| | Inside rear view mirror69 | Replacing435 |
| | Interior lights | Wattage512 |
| | Interior lights319 | Lights |
| | Switch321 | Door courtesy lights319 |
| | Wattage512 | Emergency flasher switch442 |
| | | Fog light switch161 |
| J | Jack | Hazard light switch442 |
| | Positioning a floor jack382 | Headlights switch158 |
| | Vehicle-equipped jack477 | Interior light switch321 |
| | Jack handle477 | Outer foot lights319 |
| | | Personal light switch321 |
| K | Keyless entry39 | Replacing light bulbs435 |
| • | Keys | Shift lever light319 |
| | Electronic key24 | Turn signal lever143 |
| | Engine switch130 | Vanity lights330 |
| | If you lose your keys488 | Wattage512 |
| | If the electronic key does not | Load capacity203 |
| | operate properly489 | |
| | Key number24 | M Maintenance |
| | Keyless entry | Do-it-yourself maintenance 378 |
| | Keys24 | General maintenance374 |
| | Mechanical key25 | Maintenance data502 |
| | Wireless remote control key39 | Maintenance requirements372 |
| | vvir eiess remote control key | . idinteriarioe regainements |
| | | |

| | Meter | |
|--------|--|--|
| | Instrument panel light control148 | |
| | Meters146 | |
| | Micro dust and pollen filter214 | |
| | Mirrors | |
| | Inside rear view mirror69 | |
| | Side mirror heater218 | |
| | Side mirrors71 | |
| | Vanity mirrors330 | |
| | Moon roof76 | |
| | MP3 disc238 | |
| | Multi-information display153 | |
| | | |
| | | |
| N | Noise from under vehicle19 | |
| N | Noise from under vehicle19 | |
| N O | Noise from under vehicle19 Odometer146 | |
| | | |
| | Odometer146 | |
| | Odometer146 Oil | |
| | Odometer146 Oil Engine oil386 | |
| | Odometer146 Oil Engine oil386 Opener | |
| | Odometer | |
| | Odometer 146 Oil Engine oil 386 Opener Fuel filler door 80 Hood 381 | |
| | Odometer 146 Oil Engine oil 386 Opener Fuel filler door 80 Hood 381 Trunk 46 | |
| | Odometer 146 Oil Engine oil 386 Opener Fuel filler door 80 Hood 381 Trunk 46 Outer foot lights | |

| Outside rear view mirrors | |
|-----------------------------|-----|
| Adjusting and folding | 71 |
| Mirror position memory | 51 |
| Outside temperature display | 154 |
| Overhead console | 325 |
| Overhead courtesy lights | |
| Overhead courtesy lights | 319 |
| Wattage | 512 |
| Overheating, Engine | 495 |
| | |
| Parking assist sensors | 181 |
| Parking brake | |
| Parking lights | |
| Replacing light bulbs | 435 |
| Switch | |
| Wattage | 512 |
| PCS | |
| Personal lights | |
| Switch | 321 |
| Power outlet | 337 |
| Power windows | |
| Pre-collision system | |
| | |
| | |

| R | Radar cruise control | 169 | Seat heaters | 338 |
|---|---|-------|------------------------------|-------|
| | Radiator | 391 | Seat position memory | 55 |
| | Radio | 223 | Seating capacity | 203 |
| | RDS | 225 | Seats | |
| | Rear turn signal lights | | Adjustment | 50 |
| | Replacing light bulbs | 435 | Adjustment precautions | 50 |
| | Wattage | 512 | Child seats/child restraint | |
| | Rear view mirror | | system installation | 112 |
| | Compass | 354 | Cleaning | 369 |
| | Rear window defogger | 218 | Driver's seat position memo | ry 51 |
| | Replacing | | Front passenger seat positio | n |
| | Electronic key battery | 417 | memory | 55 |
| | Fuses | 419 | Head restraints | 57 |
| | Light bulbs | 435 | Properly sitting in the seat | 89 |
| | Reporting safety defects for | | Seat heaters | 338 |
| | U.S. owners | 536 | Service reminder indicators | 150 |
| | | | Shift lever | |
| S | Safety connect | 358 | If the shift lever cannot be | |
| | Seat belts | | shifted from P | 487 |
| | Adjusting the seat belt | 61 | Transmission | 134 |
| | Automatic locking retract | | Shift lever light | 319 |
| | Child restraint system | | Shift lock system | 487 |
| | installation | 112 | Shopping bag hooks | 345 |
| | Cleaning and maintaining | | Side airbags | 91 |
| | the seat belts | 370 | Side marker lights | |
| | Emergency locking retrac | tor62 | Switch | 158 |
| | How to wear your seat be | | Side mirrors | |
| | How your child should we | ear | Adjusting and folding | 71 |
| | the seat belt | 63 | Mirror position memory | 51 |
| | Pregnant women, | | Smart access system with | |
| | proper seat belt use | 62 | push-button start | |
| | Reminder light | | Entry function | 28 |
| | C . I I I | / 2 | Starting the engine | 130 |
| | Seat belt extenders | 63 | Starting the engine | |
| | Seat belt extenders Seat belt pretensioners | | "SOS" button | |

| Spare tire |
|--|
| Inflation pressure408 |
| Storage location477 |
| Spark plug508 |
| Specifications502 |
| Speedometer146 |
| Steering wheel |
| Adjustment67 |
| Audio switches267 |
| Steering wheel position |
| memory51 |
| Storage feature |
| Stuck |
| |
| lf your vehicle becomes stuck498 |
| It your vehicle becomes stuck 498 Sun visors |
| · · |
| Sun visors |

| Power door lock switch | 42 |
|------------------------------|---------|
| Power window switch | 73 |
| Satellite switches | 332 |
| SNOW switch | 136 |
| Transmission shift | |
| switches13 | 37, 139 |
| Window lock switch | 73 |
| Wiper and washer switch | 162 |
| | |
| Tachometer | 146 |
| Tail lights | |
| Switch | 158 |
| Talk switch | 293 |
| Telephone switch | 293 |
| Theft deterrent system | |
| Alarm | 85 |
| Engine immobilizer system | 83 |
| Theft prevention labels | |
| Tire inflation pressure | 408 |
| Tire information | |
| Glossary | 521 |
| Size | 518 |
| Tire identification number | 518 |
| Uniform tire quality grading | 519 |
| | |

| Tires | | Turn signal lights | |
|------------------------------|--------|-------------------------------|---------|
| Chains | 204 | Replacing light bulbs | 435 |
| Checking | 397 | Switch | |
| If you have a flat tire | 477 | Wattage | 512 |
| Inflation pressure | 408 | | |
| Inflation pressure sensor | 397 | USB port24 | 16. 254 |
| Information | 516 | | , |
| Replacing | 477 | V Vanity lights | |
| Rotating tires | 397 | Vanity lights | 330 |
| Size | 511 | Wattage | |
| Snow tires | 204 | Vanity mirrors | |
| Tools | 477 | VDIM | |
| Total load capacity203 | | Vehicle dynamics integrated | 107 |
| Towing | | management | 187 |
| Dinghy towing | 207 | Vehicle identification number | |
| Emergency towing | 443 | Vehicle stability control | |
| Trailer towing | 206 | Voice command switch | |
| TRAC | 187 | VSC | |
| Traction control | 187 | V 3C | 107 |
| Transmission shift switches1 | 37,139 | W Warning huzzers | |
| Trip meter | 146 | VVairining buzzers | 450 |
| Trunk | | Brake system | |
| Extending trunk space | 341 | Open door | |
| Opener | 46 | Seat belt reminder | 430 |
| Trunk light | | | |
| Trunk light | 47 | | |
| Wattage | 512 | | |

Warning lights Anti-lock brake system454 Brake assist system454 Brake system......453 Charging system......454 Electric power steering warning light......454 Low fuel level......456 Malfunction indicator lamp 454 Master warning light......456 Open door456 Pre-collision system......454 Pretensioners454 Seat belt reminder light......456 SRS airbags......454 Tire pressure warning light......456

| warning messages | |
|--------------------------|----------|
| Automatic transmission | |
| fluid | 467 |
| Dynamic radar | |
| cruise control | 465, 467 |
| Engine oil level | 467 |
| Engine oil maintenance | 467 |
| Engine oil pressure | 464 |
| Engine oil temperature | 464 |
| Headlight | 465 |
| Hood | 467 |
| Intuitive parking assist | 465, 467 |
| Moon roof | 467 |
| Open door | 467 |
| Parking brake | 467 |
| Pre-collision system | 465, 467 |
| Smart access system with | |
| push-button start | 473 |
| Steering lock | 465 |
| Trunk | 467 |
| Washer fluid | 467 |
| Washer | |
| Checking | 396 |
| Preparing and checking | |
| before winter | 204 |
| Switch | 162 |
| Washing and waxing | 366 |
| | |

| Weight | |
|-----------------------------|-----|
| Cargo capacity | 200 |
| Load limits | 203 |
| Weight | 502 |
| Wheels | 412 |
| Window glasses | 73 |
| Window lock switch | 73 |
| Windows | |
| Power windows | 73 |
| Rear window defogger | 218 |
| Washer | 162 |
| Windshield wipers | 162 |
| Windshield wiper de-icer | 219 |
| Wireless remote control key | |
| Replacing the battery | 417 |
| WMA disc | 238 |